


Camera connection

The camera cord is provided only when you buy the backup camera from us.



1. Red wire-connect to "**BACK/REVERSE**" wire (blue or orange color) from main harness.
(This is reverse trigger wire, if connect incorrectly, the screen will not change when reverse the car)
2. Yellow RCA jack connect to "**Backacar VIDEO IN**" jack (yellow color) of navigation unit.
(This is the camera video input jack, if connect incorrectly, the screen will display no signal when reverse the car)
3. Black wire-connect to **NEGATIVE of reverse light** (NOT license plate light).
4. Red wire-connect to **POSITIVE of reverse light** (NOT license plate light).